

## Air Source Heat Pump Unit with Air Duct



Model applicable:  
**010CA-100/010CA-150/010CA-200/010CA-250/010CA-300**

Air source hot pump unit is in the process of production, strictly following designing standard, to make sure the high quality, high reliability and good suitability. This manual includes all the necessary information for right installation, debugging, starting and maintenance. Please read this manual carefully before you start or check the unit; The installation has to be made by disciplined technicians; Will not stand responsibility of the damage to human or units with wrong installation and debugging or not abiding by the manual.

The vital conditions to guarantee are as the following:

- The units are started or repaired by the people from service centres or appointed company man;
- According to the manual, the running or maintenance of all the units has to be made, strictly in stated time and by stated times;
- The spare parts from factory have to be used to repair.

If disobeying the conditions above, the guarantee will be invalidated automatically!

Models	Mahrw	010CA-100	010CA-150	010CA-200	010CA-250	010CA-300
Water tank volume	L	100	150	200	250	300
Hot water produced volume	L/H	75	75	75	75	75
Thermostat factory setting	°C	55	55	55	55	55
Thermostat maximum setting	°C	60	60	60	60	60
Rated heating capacity	W	3000	3000	3000	3000	3000
	BTU	10230	10230	10230	10230	10230
Power supply	V/PH/Hz	220/1/50	220/1/50	220/1/50	220/1/50	220/1/50
Rated Input power	W	950	950	950	950	950
Heating input power	W	1500	1500	1500	1500	1500
Maximum input power	W	2735	2735	2735	2735	2735
Running current	A	4,32	4,32	4,32	4,32	4,32
Working ambient temperature	°C	-7° ~ 43°	-7° ~ 43°	-7° ~ 43°	-7° ~ 43°	-7° ~ 43°
Noise	dB	43	43	43	43	43
Hot water outlet	inch	G3/4	G3/4	G3/4	G3/4	G3/4
Cooling water inlet	inch	G3/4	G3/4	G3/4	G3/4	G3/4
Tank rated water pressure	Mpa	0,2-0,6	0,2-0,6	0,2-0,6	0,2-0,6	0,2-0,6
Net Dimensions	mm	570x1450	570x1600	570x1700	700x1684	700x1864
Shipping dimensions	mm	630x630x1620	630x630x1720	630x630x1820	780x780x1824	780x780x2004
Net weight	Kg	54	58	72	79	86

## 2)、 The unit appearance and features



\* **High efficiency:** smart design make normal working efficiency more than 300%.

\* **Easy installation and operation:** With LCD display, easy to handle and check all kind of temp and operation information.

\* **Stainless steel tank:** ensure clean water to users.

- **Waste heat is useful heat**

The standard heat exchanger of the hot-water heat pump enables direct connection to a second heat generator, e.g. a solar heating system or a boiler.


- **Dehumidification in the recirculating air mode**

Dehumidified air in the laundry room supports laundry drying and prevents moisture-induced damage.

- **Cooling in the recirculating air mode**


The room air is extracted from the storage room or a wine cellar, subsequently cooled and dehumidified in the heat pump and finally re-introduced into the room. Recreation rooms, boiler rooms or utility rooms are ideal installation sites. The air-ducts leading through warm sections must be insulated to prevent the formation of condensation.

### 3).Working principle of air water units.



Sketch map of central offering hot water system

### 4).Installation of sketch map



1). to choose a right model

- ◆ Please choose the model with right water tank capacity according to the actual need for the energy saving and convenient use;
- ◆ This air source hot water heat pump is used for providing hot water for home use;

2). installation requirement and location

- ◆ The unit must be installed indoor and free from rain; There must be sufficient water supply near the unit; The unit must be installed horizontally. At air inlet and outlet, please connect ducted pipes to avoid that the return air goes into air outlet!

3). water pipe connection

Please keep below points in mind when the water pipe is connected:

- ◆ To make the water resistance inside of the pipe as low as possible
- ◆ To keep the water pipe clean and free from dirty; when the connection is made there must be testing on the leaking; Ensuring there is no leak on the pipe then the insulation can be made;
- ◆ There must be one way valve and check valve installed on the water inlet pipe.

4). electrical wire connection

- ◆ There is a power cable in the bottom of the unit which can be connected to the electric power by the users.

5). transit

- ◆ There must not be something on top of the unit, and keep it free from strike and extrusion during the transit

6). trial running

6.1 Checkup before the trial running


- ◆ Check whether the water tank is full, or whether the insulation for the pipe is good;
- ◆ Check the electrical connection: check whether the voltage is normal, whether the wire connection is good and whether the earthing is made;
- ◆ Check the unit: check whether the screw and parts is good enough; and check if the indicator light on the controller is working fine or any failure alarm as it get power;

6.2 trial running

- ◆ Turn on the unit with the wire controller
- ◆ Keep ear on the sound from the compressor when it start; if there is any sound abnormal the unit must be stoped and checked;
- ◆ Look into the tank water to see whether the water temperature fluctuation is normal;
- ◆ The parameter of the wire controller has been settled in the factory, they cannot be reset by the users; Please return to the qualified service man if the parameter need to be changed.

1).Function of water tank controller


User Interface and Usage as the following:



2). Use of the controller of water tank


1) Electrify

After checking everything is ok, electrify and enter into standby state , with the screen showing as the following:




2) Turn-on.

Press "⏻" to turn on the unit with the screen showing as the following:





3) Turn-off


Press “” to turn off the unit with the screen showing as the following:



Time display (24 hours, e.g. the screen shows 20:00 P.M.)

4) Check parameters




During running or standby state, press  or  to check the related parameters with the screen showing as the following:



The parameter value

“1” means the parameter code

5) check and change the set parameters (Note: you can check and change the set parameters during standby state but you can only check the set parameters when the unit running )

1. Press “ ” again and again to check the related set parameters;
2. Then press “ELEC. HEATING” “” at the same time ,to change the parameters; If without press within 5 seconds, it will exit setting state;

The screen displays as the following :



To show the set parameter

To show parameter No. 0 — 9  
(please check the system parameter table for the related meanings)

6) Malfunction Display

During standby or running state , if malfunction happens to the system, the system will stop to show the malfunction code as the following:



To show the malfunction code  
(refer to malfunction code table)

### 1). Maintenance

- ◆ A water filter must be working with the unit, and it must be cleaned periodically in order to provide clean water and avoid dirty and block to the unit.
- ◆ There must be dry, clean and good ventilation around the unit; the heat exchanger must be cleaned every 1 or 2 month to keep the heat exchanger efficiency and save energy;
- ◆ Please check with every part of the unit regularly; and check whether the system pressure is normal, it must be maintained or replaced if there is any abnormal;
- ◆ Please check with the power supply and wire connection regularly, and look whether there is any abnormal action or odor, it must be replaced if necessary;
- ◆ If the unit is not running for a long time, it must be sealed and maintained, and also drain the water in the unit; When the unit is restarted, the water must be refilled to the unit and check the unit entirely;

### 2). The normal failure and solutions

Failure	Controller on the water tank	Indicator light	Cause	Solutions
Power on		Off		
Unit running		On		
Lower tank water temp. sensor failure	P1	1 on 1 off	The temp. sensor is open or short circuit	Check and replace the temp. sensor for the upper tank water
Upper tank water temp. sensor failure	P2	2 on 1 off	The temp. sensor is open or short circuit	Check and replace the temp. sensor for the lower tank water
Inlet evaporator temp. sensor failure	P3	3 on 1 off	The temp. sensor is open or short circuit	Check and replace the temp. sensor for the evaporator inlet
Outlet evaporator temp. sensor failure	P4	4 on 1 off	The temp. sensor is open or short circuit	Check and replace the temp. sensor for the evaporator outlet
Exhaust temp. sensor failure	P5	5 on 1 off	The temp. sensor is open or short circuit	Check and replace the temp. sensor for the exhaust
High pressure protect	E1	6 on 1 off	1.too much refrigerant in the unit 2.bad heat exchange on the air	1. discharge the redundant gas 2. clean the air side heat exchanger
Low pressure protect	E2	7 on 1 off	1.the refrigerant is not enough 2.block on the filter or capillary 3.water flow is not enough 4.expansion sensor is broken	1.check if there is any leak and refill the gas 2.replace the filter or capillary 3.clean the water side exchanger or discharge the air in the water loop 4.use new expansion valve
AUX-heating thermal protect	E3	8 on 1 off	The electronic heating temp. protect	Check the water supply or tank whether have enough water
Compressor exhaust temp. too high	E4	9 on 1 off	Compressor exhaust temp.too high	Check through the refrigerant system
Communication failure	E8	On	Communication failure between wire controller and main board;	Check the wire connection between the wire controller and the main board
Defrosting	Defrosting indicate	flash		

1).Parameters for unit running

Parameter	Meaning	Range	Default	Remarks
0	return water temp. in the tank	10-70°C	55°C	Adjustable
1	heating differential	2-15°C	5°C	Adjustable
2	tank water temp. for starting e-heater	10-90°C	55°C	Adjustable
3	e-heater delay time T	0-90min	40min	Adjustable
4	high water temp. for antiseptis per week	60-90°C	65°C	Adjustable
5	high water temp. period for week	10-90min	30min	Adjustable
6	defrosting period	30-90min	45min	Adjustable
7	coil temp. for starting defrosting	0-30°C	-7°C	Adjustable
8	coil temp. for exit defrosting	2-30°C	13°C	Adjustable
9	defrosting period	1-12min	8min	Adjustable
10	To adjust the electrical expansion valve	0/1	1	Adjustable
11	Target over-heat degree (when parameter10=1, it will take effect)	-20°C- 20°C	5°C	Adjustable
12	Step to adjust the electrical expansion valve by hand	10-50	35	Adjustable
A	Inlet water temp.	-9-99°C		True testing figure; show P1 if there is any failure
B	Outlet water temp.	-9-99°C		True testing figure; show P2 if there is any failure
C	Evaporator coil temp.	-9-99°C		True testing figure; show P3 if there is any failure
D	Evaporator temp.	-9-99°C		True testing figure; show P4 if there is any failure
E	Exhaust temp.	-9-199°C		True testing figure; show P5 if there is any failure
F	Eletronic expansive valve step	0-50	N*10	

Remarks: Electric-heater starting time after compressor is parameter 03 plus 5.

2). Controlling board access

